

# CHM201 Spectroscopy and other Physical Methods

Spectral Problems

# Nuclear Magnetic Resonance – Spectral Problems Solving

Information from  $^1\text{H-NMR}$  Spectral Data:

1. **Number of signals** – Information on symmetry & types of protons
2. **Nature of the peak** – Information on relaxation/hydrogen bonding
3. **Chemical Shift** – Local environment around the proton
4. **Splitting pattern (multiplicity)** – Neighboring group & connectivity
5. **Integral values** – Number of protons or proton ratios
6. **Coupling constant** – Geometrical position of coupling partner

Solving  
structure  
of  
molecules

$$\nu_{\text{eff}} = (\gamma/2\pi) B_0 (1 - \sigma)$$

where

a = No. of carbon atoms (Tetravalent)

b = No. of hydrogen atoms (Monovalent)

c = No. of nitrogen atoms (Trivalent)

d = No. of oxygen atoms (Divalent)

e = No. of sulphur atoms (Divalent)

f = No. of halogen atoms (Monovalent)

For a compound of molecular formula  $\text{C}_a\text{H}_b\text{N}_c\text{O}_d\text{S}_e\text{X}_f$


$$\text{Double bond equivalent} = (a + 1) - \frac{b - c + f}{2}$$

# Nuclear Magnetic Resonance – Spectral Problems Solving


**Problem 1:** Predict the number of signals in  $^1\text{H-NMR}$  for the following compounds.




2




4



3





2



5

**Problem 2:** What will be the nature of the signals at the indicated protons?




Broad

OH

Broad

NH<sub>2</sub>





Broad

Broadness can be due to

1. Hydrogen bonding
2. Quadrupolar nuclei
3. Dynamics (conformational)

# Nuclear Magnetic Resonance – Spectral Problems Solving

Chemical Shifts in terms of shielding and deshielding



Higher frequency  
less shielding  
deshielded




Lower frequency  
more shielding  
shielded

600 MHz

v (Hz)	6000	5400	4800	4200	3600	3000	2400	1800	1200	600	0
$\delta$ (ppm)	10	9	8	7	6	5	4	3	2	1	0


# Nuclear Magnetic Resonance – Spectral Problems Solving

Factors affecting chemical shift



$\text{CH}_3\text{F}$	$\text{CH}_3\text{Cl}$	$\text{CH}_3\text{Br}$	$\text{CH}_3\text{I}$	$\text{CH}_3\text{CH}_3$	$\text{CH}_4$	$\text{CH}_3\text{SiMe}_3$	$\text{CH}_3\text{Li}$
4.26	3.05	2.69	2.19	0.96	0.2	0.0	-2.1


Electronegativity



Number of electronegative atoms increase  
Chemical Shift increase


# Nuclear Magnetic Resonance – Spectral Problems Solving

Factors affecting chemical shift  
Electron donating and electron withdrawing groups




# Nuclear Magnetic Resonance – Spectral Problems Solving




NMR spectrum of acetylacetone



# Nuclear Magnetic Resonance – Spectral Problems Solving




**Problem 3:** Predict the number of signals, and approximate chemical shifts.




Reason: Resonance structure

Reason: Inductive effect

# Nuclear Magnetic Resonance – Spectral Problems Solving



$^1\text{H}$  NMR (400 MHz,  $\text{CDCl}_3$ ):  $\delta$  7.71-7.64 (m, 2H),  
7.57-7.50 (m, 1H),  
7.48-7.39 (m, 2H),  
4.41 (q,  $J = 7.1$  Hz, 2H),  
1.43 (t,  $J = 7.1$  Hz, 3H).



Spin – spin coupling

$^x\text{J}$      $x = \text{Number of intervening bonds}$


General formula for determining coupling =  $2nI + 1$

$n = \text{Number of nuclei at neighboring position}$


<u><math>n</math></u>	Multiplicity	Relative Intensity	Spins	Coupling Pattern
0	Singlet (s)		$n = 1$	
1	Doublet (d)		$n = 2$	
2	Triplet (t)		$n = 3$	
3	Quartet (q)			
4	Quintet			
5	Sextet			
6	Septet			
7	Octet			
8	Nonet			

# Nuclear Magnetic Resonance – Spectral Problems Solving


## $^3J$ (Vicinal) coupling




2-9





6-14




11-18




4-10



10-13



3-7




1-3




2-3

$$\begin{aligned} J_o &= 7-10 \\ J_m &= 2-3 \\ J_p &= 0.1-1 \end{aligned}$$

## $^2J$ (Geminal) coupling




12-20



0-3.5

*Ortho, meta and para coupling*

## Conformational influence in coupling



For a methyl group, the observed coupling is the average of the three couplings, since these will be fully averaged by methyl rotation:


$${}^3J_{\text{obs}} = \frac{J_g + J_g + J_a}{3} = \frac{4 + 4 + 13}{3} = 7$$

# Nuclear Magnetic Resonance – Spectral Problems Solving


Problem - 1




IR ( $\text{cm}^{-1}$ ): 3005, 1716, 1358,  
1220, 529




Problem - 2




Problem - 3




2  
3



Problem - 4





2  
1






# Nuclear Magnetic Resonance – Spectral Problems Solving


**Problem 5:** For each spectrum below, choose between the alternative compounds.



or





or





# Nuclear Magnetic Resonance – Spectral Problems Solving


Problem - 6





Problem - 7



Problem - 8






# Nuclear Magnetic Resonance – Spectral Problems Solving










**Problem - 9**



**Problem 10:** Based on the available  $^1\text{H}$  &  $^{13}\text{C}$  spectral data, identify the correct compound from the options:



**Problem 11:** Based on the available  $^1\text{H}$  spectral data, identify the correct compound from the options:




<i>frequency, cm<sup>-1</sup></i>	<i>bond</i>	<i>functional group</i>
3640–3610 (s, sh)	O–H stretch, free hydroxyl	alcohols, phenols
3500–3200 (s, b)	O–H stretch, H–bonded	alcohols, phenols
3400–3250 (m)	N–H stretch	1°, 2° amines, amides
3300–2500 (m)	O–H stretch	carboxylic acids
3330–3270 (n, s)	–C≡C–H: C–H stretch	alkynes (terminal)
3100–3000 (s)	C–H stretch	aromatics
3100–3000 (m)	=C–H stretch	alkenes
3000–2850 (m)	C–H stretch	alkanes
2830–2695 (m)	H–C=O: C–H stretch	aldehydes
2260–2210 (v)	C≡N stretch	nitriles
2260–2100 (w)	–C≡C– stretch	alkynes
1760–1665 (s)	C=O stretch	carbonyls (general)
1760–1690 (s)	C=O stretch	carboxylic acids
1750–1735 (s)	C=O stretch	esters, saturated aliphatic
1740–1720 (s)	C=O stretch	aldehydes, saturated aliphatic
1730–1715 (s)	C=O stretch	α, β–unsaturated esters
1715 (s)	C=O stretch	ketones, saturated aliphatic
1710–1685 (s)	C=O stretch	α, β–unsaturated aldehydes
1685–1666 (s)	C=O stretch	α, β–unsaturated ketones
1680–1640 (m)	–C=C– stretch	alkenes
1650–1580 (m)	N–H bend	1° amines
1600–1585 (m)	C–C stretch (in–ring)	aromatics
1550–1475 (s)	N–O asymmetric stretch	nitro compounds
1500–1400 (m)	C–C stretch (in–ring)	aromatics
1470–1450 (m)	C–H bend	alkanes
1370–1350 (m)	C–H rock	alkanes
1360–1290 (m)	N–O symmetric stretch	nitro compounds
1335–1250 (s)	C–N stretch	aromatic amines
1320–1000 (s)	C–O stretch	alcohols, carboxylic acids, esters, ethers
1300–1150 (m)	C–H wag (–CH <sub>2</sub> X)	alkyl halides
1250–1020 (m)	C–N stretch	aliphatic amines
1000–650 (s)	=C–H bend	alkenes
950–910 (m)	O–H bend	carboxylic acids
910–665 (s, b)	N–H wag	1°, 2° amines
900–675 (s)	C–H “oop”	aromatics
850–550 (m)	C–Cl stretch	alkyl halides

**Table of characteristic IR absorptions**






\* m = medium, w = weak, s = strong, n = narrow, b = broad, s = sharp.


## Useful infrared characteristic frequencies







\*Free OH, medium and sharp; bonded OH, strong and broad

1. Identify the compound from the given options based on the infrared signals. Assign the key and characteristic signals for identification.











NIST Chemistry WebBook (<http://webbook.nist.gov/chemistry>)








### INFRARED SPECTRUM








NIST Chemistry WebBook (<http://webbook.nist.gov/chemistry>)



### INFRARED SPECTRUM






## 2. Match the infrared spectra "1 – 6" with the correct molecules given:

INFRARED SPECTRUM


TRANSMITTANCE



**1**




INFRARED SPECTRUM

Relative Transmittance






**2**

NIST Chemistry WebBook (<http://webbook.nist.gov/chemistry>)




NIST Chemistry WebBook (<http://webbook.nist.gov/chemistry>)



TRANSMITTANCE

INFRARED SPECTRUM




**3**

NIST Chemistry WebBook (<http://webbook.nist.gov/chemistry>)



Relative Transmittance

INFRARED SPECTRUM



**4**



NIST Chemistry WebBook (<http://webbook.nist.gov/chemistry>)



NIST Chemistry WebBook (<http://webbook.nist.gov/chemistry>)



3. Identify the compounds “a – i” based on the spectral details and the structures given below:

- a. 3080 (w), nothing 3000–2800, 2230 (s), 1450 (s), 760 (s), 688 (s)
- b. 3380 (m), 3300 (m), nothing 3200–3000, 2980 (s), 2870 (m), 1610 (m), ~900–700 (b)
- c. 3080 (w), nothing 3000–2800, 1315 (s), 1300 (s), 1155 (s)
- d. 2955 (s), 2850 (s), 1120 (s)
- e. 2946 (s), 2930 (m), 1550 (s), 1386 (m)
- f. 2900 (b, s), 1720 (b, s)
- g. 3030 (m), 730 (s), 690 (s)
- h. 3200–2400 (s), 1685 (b, s), 705 (s)
- i. 3350 (s), 3060 (m), 1635 (s)

s = strong, m = medium, w = weak, b = broad

